

DIRECTIONS FOR USE

Dy-Mark

Long Arm Handle Ref Code: 40080105

STEP 1 Insert aerosol can into can holder as shown in the orientation below.



STEP 2 Continue to insert the aerosol can into the can holder until it slides over the spring bracket & you hear a clicking sound.



STEP 3
Rotate the aerosol can and/or the trigger actuator to ensure the trigger cap is aligned with the trigger actuator.



STEP 4 Pull trigger to spray.



Example of how to use the Long Arm Handle.

Note: Only compatible with the following products which have the upright/inverted spray nozzle (Trigger cap), as shown below:

